DC166 Quick Start Guide

Lumens

⚠ Important

- * Please activate your warranty at www.lumens.com.tw/reg
- * Please visit our website www.lumens.com.tw/goto.htm to download latest version of Software, Multilingual User Manual and Quick Start Guide.

1. Package Contents

Main Unit



Quick Start Guide




*To download this manual in other languages, visit Lumens website





Remote control



VGA Cable

USB Cable



C-Video Cable



RS232 Adapter (Optional)



Power Cord



* Appearance may vary in different countries

Microscope Adapter




Accessory Pouch



Presenter Protector Bag







Backlight Padded Carry (Optional) Bag (Optional)



2. Getting Started




- 1 Place an object to be displayed under the camera.
- 2 Turn the power on.
- 3 Adjust the gooseneck and lens to appropriate position.
- 4 Press the [AUTO TUNE] button to optimize the image.
 You are ready to teach / present.
 - * Each time the camera head is moved, press the [FOCUS] button to refocus the lens.






▼ Connect to a Projector or Monitor




▼ Connect to a Computer and Use Lumens' Software.




* Driver and software can be downloaded from Lumens website.

▼ Connect a Projector, Computer simultaneously




* Press [SOURCE] to change image source from Computer.

▼ Connect to an Interactive Whiteboard (IWB)




▼ Connect to a TV



* NTSC: USA, CANADA, MEXICO, PANAMA, CHILE, JAPAN, TAIWAN, KOREA AND PHILIPPINES.

* After the unit is re-started, new DIP switch configuration is effective.

▼ Connect to an Computer via RS232



^{*} PAL: Country / region not listed above.